

MSP432P401R
Flight controller

MSP432P401R
Reset trigger

RST

P2.7

GND

1 k Ω

GND

Serial port (USB)

Serial port (USB)

Host
Running pythonHost.py