

About Battery and Charger

Important Note

Charge the battery before first use to make it have enough power.

Charge the battery before completely drained. In addition, different devices need different power level when using. Charge the battery in time to make your device work well.


Do not short positive and negative ends of batteries.

How to use?

The flat end of battery is the negative pole and the sharp end is the positive pole.



Connect the USB cable



Find any available USB port



Charging



Fully charged

About security

When you leave the charger for a very long time, disconnect the charger with power resource.

Do not throw battery to fire, water, conductive solution or corrosive solution.

Put the idle battery into plastic box.