









Cut the solder trace connecting B_OCTAVE to pin 5, instead solder a wire connecting the button to pin 8



Mistakes that made it to the production:
The resistor must be connected between 3v3 and PC2 instead
(this can be fixed on board by connecting the upper leg of the resistor to left pin of a C5 instead)



TODO: CALCULATE THE RIGHT VALUES



Sheet: /
File: stylophone-board.kicad_sch

Title: Stylophone

Size: A4 Date: 2025-07-11

KiCad E.D.A. 9.0.3

Rev: 0.1

Id: 1/1