

ADAR1000 Evaluation Software Install Guide

- ▶ Download the SDP driver installer [here](#)
 - Run the SdpPanelInstaller.exe
 - Choose the directory location
 - Follow instructions to Finish
 - This installs the SDP board drivers
- ▶ Run the ADAR1000.exe file
 - Connect the SDP board to the PC and evaluation board
 - Click the 'Connect' button on the Connections tab
 - The connection status at the bottom should say connected

