

Pin #-- On Gun -- Keyboard/Mouse Button-- In Code

TRIGGERS & CALIBRATE

10 ---- Trigger ----- Mouse Left ----- Trigger
16 ---- 2nd Trigger----- Mouse Right ---- Reload
14 ---- Front Button --- F4 ----- Calibrate

BUTTONS ON FRONT GRIP

9 --- Front Left ----- Left Control ---- A Button
8 --- Front Right ----- Left Shift ---- B Button
7 --- Back Left ----- 2 ----- Start
6 --- Back Right ----- 6 ----- Select

DPAD BUTTONS


A0 -- Up ----- Up Arrow ----- Up
A1 -- Down ----- Down Arrow ----- Down
A2 -- Left ----- Left Arrow ----- Left
A3 -- Right ----- Right Arrow ----- Right

RAW - Power

OTHER NEEDED PINS

2 ---- SDA on Camera
3 ---- SCL on Camera
VCC -- POWER for Camera
GND -- Ground Pins
Your Buttons & Camera Need To Be Grounded

15-----Motor
4-----NeoPixel



TITLE: Sheet_1		REV: 1.0
	Company: Your Company	Sheet: 1/1
	Date: 2023-07-28	Drawn By: Muhammad Hasnat