



100
35V
RVT

100
35V
RVT

100
35V
RVT

v4.2.3

ARM
CPU
STM32F103RET6

The Firmware in This Repository
Only Works With This CPU

LCD
PORT

20amp FUSE
02

24v From Power Supply

Wire Ferrules
On all screw terminal
connections

Hot End &
Case Fans

Heated
Bed

Hot End
Heater

Parts Fan 2

Parts Fan 1

Filament
Sensor
(Off By Default)

End Stop End Stop End Stop

BL/CR Touch

BED

HOT
END

TB

TH