



https://github.com/GadgetReboot/Rotary_USB
<https://www.youtube.com/gadgetreboot>

Gadget Reboot

Sheet: /
 File: Rotary_USB.kicad_sch

Title: LS30 Rotary Joystick USB Interface

Size: A Date: 2024-12-09
 KiCad E.D.A. 8.0.5

Rev: 1
 Id: 1/1