



Label	Definition
UP	Increase timer duration If pushed down for longer than 1 seconds, increase at 10 Hz frequency
DOWN	Decrease timer duration If pushed down for longer than 1 seconds, decrease at 10 Hz frequency
START-SAVE	Start timer and activate necessary motors, heating, etc. Save timer value to EEPROM
ALARM-STOP	If timer reached 0, blink LED display at 1 Hz and activate buzzer.
BZ-DISABLE	If necessary, disable buzzer

Geist R&D

Sheet: /  
File: PCB\_Etching\_Unit.kicad\_sch

Title: Etching-Unit-0

Size: A4 Date: 2025-12-23

KiCad E.D.A. 9.0.6

Rev: 0

Id: 1/1