



- P1 – To X Motor and X/Y Limit Switches
- 1.1 A–
  - 1.2 A+
  - 1.3 B–
  - 1.4 B+
  - 1.5 GND
  - 1.6 X–HOME
  - 1.7 Y–HOME
  - 1.8 +5
- P2 – To RPi–CNC X/Y Limit Switch Connector
- 1.1 GND
  - 1.2 N/C
  - 1.3 X–HOME
  - 1.4 Y–HOME
- P3 – To RPi–CNC Spindle Connector
- 3.1 GND
  - 3.2 LASER FIRE
  - 3.3 N/C
  - 3.4 N/C
- P4 – To Power Supply Laser Connector
- 4.1 N/C
  - 4.2 GND
  - 4.3 +5
  - 4.4 LASER FIRE
- P5 – To Y axis stepper driver
- See P1 pins 1–4

Hobart Makers		
Created by: Scott Bragg		
Checked by:		
Notes added: Geoff Steer		
Sheet: /		
File: K40–interface.kicad_sch		
Title: K40 Interface		
Size: User	Date: 2021–08–08	Rev: 1
KiCad E.D.A. kicad 5.99.0–unknown–c8944286c0~131~ubuntu21.04.1		Id: 1/1