

Engine & Performance

Issue: Car won't start

Possible causes: Battery dead, starter issue, immobilizer, key fob problem

Issue: Check engine light is ON

Possible causes: Sensor issues, emission problems, loose fuel cap

Issue: Engine overheating

Possible causes: Low coolant, radiator fan failure, thermostat issue

Issue: Loss of power while driving

Possible causes: Fuel delivery issue, turbo failure, clogged filters

Issue: Rough idling or engine stalling

Possible causes: Dirty throttle body, spark plugs, vacuum leaks

Brakes & Safety

Issue: Car shakes or vibrates when braking

Possible causes: Warped brake discs, worn brake pads

Issue: Brakes making squealing or grinding noise

Possible causes: Worn pads, brake dust, damaged rotors

Issue: Brake pedal feels soft or spongy

Possible causes: Air in brake lines, brake fluid leak

Transmission & Driving

Issue: Gear shifting is hard or delayed

Possible causes: Low transmission fluid, clutch wear, software issue

Issue: Car jerks during acceleration

Possible causes: Transmission issue, engine misfire

Issue: Burning smell while driving

Possible causes: Overheated clutch, oil leak, brake overheating

Electrical & Electronics

Issue: Battery drains quickly

Possible causes: Faulty alternator, parasitic drain, old battery

Issue: Dashboard warning lights randomly appear

Possible causes: Sensor or software malfunction

Issue: Key fob not detected / keyless entry not working

Possible causes: Weak battery, antenna issue

Issue: Infotainment system freezing or restarting

Possible causes: Software bug, system update needed

Climate & Comfort

Issue: Air conditioning not cooling

Possible causes: Low refrigerant, compressor failure

Issue: Heater not working properly

Possible causes: Coolant issue, heater core problem

Issue: Strange smell from AC vents

Possible causes: Mold, dirty cabin air filter

Steering & Suspension

Issue: Steering wheel pulling to one side

Possible causes: Wheel alignment, uneven tire pressure

Issue: Clunking or knocking noise on bumps

Possible causes: Suspension wear, loose components

Issue: Steering feels stiff or heavy

Possible causes: Low power steering fluid, steering motor issue

Tires & Exterior

Issue: Uneven or fast tire wear

Possible causes: Alignment issue, suspension problem

Issue: Car vibrates at high speeds

Possible causes: Wheel imbalance, tire defect

Issue: Wind or road noise inside the cabin

Possible causes: Door seals, tire type

Leaks & Fluids

Issue: Fluid leaking under the car

Possible causes: Oil, coolant, brake fluid, AC condensation