





Erase pins, short these to erase program then reset



Status LEDs



|                                 |         |
|---------------------------------|---------|
| Sheet: /Microcontroller/        |         |
| File: Microcontroller.sch       |         |
| <b>Title: Microcontroller</b>   |         |
| Size: A4                        | Date:   |
| KiCad E.D.A. kicad 4.0.1-stable | Rev: A  |
|                                 | Id: 3/5 |

