



Notes
1. Ignore pin numbers. Use pin names instead
2. Switch S9 overrides all the enhancement mode switches S3 - S7 (turns them on)

<https://github.com/Grommet123/GPSLCD>

TITLE: GPSLCD		REV: 4.3
Date: 2016-11-27		Sheet: 1/1
EasyEDA V3.11.3		Drawn By: GK Grotsky