

DMS7 DMS8 DMS9 DMS10 DMS11 DMS12

USB
UART

LED 3.3V
LED 5V
LED USER 1
LED USER 2
LED USER 3
LED USER 4

DMS 1

DMS 2

DMS 3

DMS 4

DMS 5

DMS 6

28V-GND
28V-GND
EXP-OUT-N
EXP-IN-N
EXP-OUT-P
EXP-IN-P

LO
NC
SOE
NC
SODS
NC
NC
28V
28V

LED 5V (28V rail)
LED 28V

TDO
28V
TRST
28V-GND
TDI
TMS
3.3V
TCK
GND

PT100 1

PT100 2

PT100 3

HERMESS Blade Rev 1

JTAG
SWD
Programming

1

3.3V	GND
TRST	GND
TDI	GND
TMS	GND
TCK	GND
TDO	NC
NC	GND

14