

Linux driver link for Ubuntu 22.04.4 LTS

[ubuntu22.04.4T6_240715.run](#)

(https://mctsharing-my.sharepoint.com/:u:/g/personal/mctsharing_mctsharing_onmicrosoft_com/EaToWG1HM0tPpYpMOboU4lEBi6FyOShpATWPRv13l-BK5Q?e=rpn1FQ)

Installation:

1. `chmod u+x ubuntu22.04.4T6_240715.run`
2. `sudo ./ ubuntu22.04.4T6_240701.run`

- ✂ It supports the products made by Trigger VI T6-688SL only.
- ✂ It does not support HDMI audio on Linux.