



M1 QMK 固件更新操作说明


1. Open the M1 QMK toolbox software



2. Click Open to find .bin file



3. Plug the USB cable out. Press ESC and plug in the cable of M1 QMK, You could find the Flash/Exit DFU turns black.



4. Click Flash to update the firmware. It finishes after the OK as below comes out. Then click Exit DFU. Close the QMK Toolbox. Re-plug the USB Cable to use the keyboard.

