










Title		
Size A3	Number	Revision
Date:	3.05.2025	Sheet of
File:	C:\work\...\bolid-inputs-digital.SchDoc	Drawn By:



Title		
Size A3	Number	Revision
Date:	3.05.2025	Sheet of
File:	C:\work\...\bold-inputs-hv.SchDoc	Drawn By:




Title		
Size A3	Number	Revision
Date:	3.05.2025	Sheet of
File:	C:\work\...\bold-inputs-lv.SchDoc	Drawn By:

A



B

C

D






R77 -> DNP













Title		
Size	Number	Revision
A3		
Date:	3.05.2025	Sheet of
File:	C:\work\boldid-iso-motor-control.SchDoc	Drawn By:

[illegible]





Title		
Size A3	Number	Revision
Date:	3.05.2025	Sheet of
File:	C:\work\...\bolid-power-input.SchDoc	Drawn By:



Title		
Size A3	Number	Revision
Date:	3.05.2025	Sheet of
File:	C:\work\...\bold-rs485-usb-sd.SchDoc	Drawn By: