


Quick start Guide

Note:

- (1. Technical support contact: penghuan@myactuator.com)
- (2. After downloading, please unzip the folder first)

1. For the first use, please open the folder 'Required Runtime Environment' to install the environment and driver (If you find anything wrong, please contact technical support.)



2. To run the Setup Software, please click on the executable file with the icon 'MYACTUATOR Setup Software xxxxxx.exe'.

