

Zoom In



Allows to Zoom In within the map

Zoom Out



Allows to Zoom Out within the map

Municipality




Allow to zoom to Municipality

Info



Provides the info of the selected item

Coordinate Information



Shows the longitude and latitude of the selected location

Locate Point by Coordinate



Shows the longitude and latitude of the searched location

Measure Distance



Measure the distance of the line drawn

Measure Area



Measure the area of the polygon drawn

Print



Prints the visible area of the map

Help



Displays the Help page

Find Nearest Road




Finds the Nearest road from the marker

Find Buildings to Containment



Displays Buildings Connected to Containments

Find Containments to Building



Find Containments
Connected to Buildings

Find Associated Buildings



Find Building associated
with Other Building

Import from WMS



On Import, a dropdown of
layers from the WMS URL
will appear. Once a layer is
selected, it will be displayed
on the map

Locate Me



Displays the user's current
location on the map

KML Drag and Drop



Simply drag and drop the
file to view the map
features on the map
interface

Remove Markers



Remove all the active tools

Ward Outline



Search the ward

Search



Search using BIN, House
Number, Places Name and
Road Code or Name