

Institute IRNAS Rač
Toolink CNC Receiver

Axis Select:
123
000-X
001-Y
010-Z



open hardware

+2V
ERROR
SLEP
DIR
ENABLE
GND