

How to Customise Your BeakBox Playlist

Pre-loaded tracks on your BeakBox have been thoroughly selected for your bird - they are soft, gentle and bird-friendly. But you can easily customize the playlist and upload your bird's favorite songs.

If you are unsure what music your birds might be interested in, we recommend playing tracks from different genres and paying attention to their body language. If your bird is enjoying the music, s/he will be quite or will be signing or 'chatting' along with the song, tilting its head or preening.

Steps to create custom playlist:

- 01** Unplug your BeakBox.
- 02** Remove the micro-SD card from the BeakBox by pulling it out.
- 03** Insert the micro-SD card into the SD-card adapter provided with the BeakBox.
- 04** Insert the adapter into the SD card slot on your computer.
- 05** Open the micro-SD card root folder in your file explorer.
- 06** Drag and drop the tunes you want to upload onto your BeakBox.
- 07** Eject the micro-SD card safely from your computer, take it out and insert back into the BeakBox.
- 08** Plug it in and enjoy your new tunes!



www.mybeakbox.com
contact@mybeakbox.com



- Before uploading your tracks onto the BeakBox, please make sure that they are in mp3 format
- Don't play loud, low-pitched or 'booming' sounds as they might distress your bird
- Always check that your birds enjoy the tunes before leaving them alone with the BeakBox