




FPGA Programmer




Power



MCU Programmer




Monocle Spring Connector



Hardware

- H1 MountingHole
- H2 MountingHole
- H3 MountingHole
- H4 MountingHole
- H5 MountingHole
- H6 MountingHole
- FID1 Fiducial
- FID2 Fiducial
- FID3 Fiducial
- FID4 Fiducial
- FID5 Fiducial
- FID6 Fiducial



References:
<https://developer.arm.com/documentation/dui0499/a/Target-Interface-Connections/SWD-connections>
https://www.keil.com/support/man/docs/ulink2/ulink2_hw_connectors.htm
<https://www.segger.com/products/debug-probes/j-link/technology/interface-description/>
<https://1bitsquared.com/products/20pin-jtag-adapter>
GoWin UG112 USB Download Cable User Guide

Designed by: tinyVision.ai inc.

Checked by: V. Rangan

Brilliant Labs Limited

Sheet: /

File: MK11_PROG.sch

Title: MONOCLE DEV BOARD

Size: A4 Date: 2021-08-31

KiCad E.D.A. kicad (5.1.6)-1

Rev: 1.0

Id: 1/1