

*configure*



*control*

LCD Display


STM32 l476-rg Controller

IR Receiver

USB Socket



IR Remote Control



Keyboard/Mouse

*command from user*

