

## Tinker Board 2 image flash SOP for Linux

1. Download flash tool  
[https://drive.google.com/file/d/14PWlq9W\\_3EK0kdLKeGJxIErDctMkCUGA/view?usp=sharing](https://drive.google.com/file/d/14PWlq9W_3EK0kdLKeGJxIErDctMkCUGA/view?usp=sharing)
2. Unzip Linux\_Upgrade\_Tool\_v1.38.zip
3. Tinker Board 2 enter MASKROM mode
  - a. short the maskrom pin



- b. Connect type-c cable to PC
  - c. Plug in the adapter
  - d. Unshort the maskrom pin
4. Flash image

```
$ cd Linux_Upgrade_Tool_v1.38
$ chmod +x upgrade_tool
$ sudo ./upgrade_tool uf [path of update.img]
```