




STM32F1 Microcontroller




8x KTIR SENSOR




UART3 - USB



TB6612FNG Right motor driver




HC-05 Bluetooth module




Motor voltage ;P

Option 1:



Option 2:



Battery voltage goes through Pololu stabs and then into drivers

Battery voltage goes straight into drivers

TB6612FNG left motor driver

