



NOTE: WITH NO INPUT PULSE (E.G LOST OF RADIO RECEPTION)
PUMPS WILL GO OFF ACTING AS A FAILSAFE

EVERYTHING IS POWERED FROM THE RECEIVER'S 5 V

SOLENOID AND PUMP CONTROLLER
FOR A STANDARD PPM RC RECEIVER

JUAN GG ON JUNE 2019

S-81 1:120 RC SUBMARINE

Sheet: 1/1