


I will send you a few steps.


1. Run this configurator. <https://config.qmk.fm/#/redox/rev1/LAYOUT>
2. By clicking the buttons in the configurators you create your dream layout.

**** Remember to install the same firmware to the master and separately to the slave.**




3. You enter your layout name.





6. Here you choose your firmware.

7. Select the "Auto-Flash" option



8. You press the reset on the bottom of the keyboard.



9. Well Done ;)
I wish you all the best and above all a lot of health.