



# 1. Connect in- and outputs





# Select the trigger mode

2.

- trigger on loud noise
- trigger on bright light
- trigger on silence
- trigger on darkness




# 3. Adjust the trigger delay



# 4. Adjust the trigger threshold


4.



Turn the threshold knob until the "ARM" LED lights up.

Turn the knob back a bit.

# 5. Activate the trigger



6.

Smile!

