



Setting

Autostart on Power On

☐ Off

Tasks to Auto-start

1

Camera Resolution

GPS Communication Mode

External Trigger

Yes

GPIO Port Number

< 0 >

Signal Output

Yes

GPIO Port Number

< 0 >