




User's Guide

Contents

Chapter 1	5 Activating and Setting Up [REDACTED]
	5 What You Need
	5 Activating [REDACTED]
	7 Syncing [REDACTED] with Your Computer
	11 Disconnecting [REDACTED] from Your Computer
Chapter 2	12 Basics
	12 [REDACTED] at a Glance
	14 Home Screen
	17 [REDACTED] Buttons and Touchscreen
	23 Using the Stereo Headset
	24 Connecting to the Internet
	26 Using [REDACTED] on an Airplane
	27 Charging the Battery
	28 Cleaning [REDACTED]
Chapter 3	29 Phone
	29 Calling and Answering
	34 Visual Voicemail
	37 Adding Contact Information to [REDACTED]
	40 Ringtones
	41 Using [REDACTED] with a Bluetooth Headset or Car Kit
	44 Calling to and from Other Countries
	45 Phone Settings
Chapter 4	46 Mail
	46 Setting Up Email Accounts
	48 Sending Email
	49 Checking and Reading Email
	51 Mail Settings

Chapter 5	52 Safari
	52 Surfing the Web
	56 Adding Safari Web Clips to the Home Screen
	56 Using Bookmarks
	57 Safari Settings
Chapter 6	58 iPod
	58 Syncing iPod Content from Your iTunes Library
	59 Playing Music
	64 Watching Videos
	67 iPod Settings
Chapter 7	68 Applications
	68 Text
	70 Calendar
	73 Photos and Camera
	77 YouTube
	80 Stocks
	81 Maps
	86 Weather
	87 Clock
	89 Calculator
	90 Notes
Chapter 8	91 Settings
	91 Airplane Mode
	92 Wi-Fi
	93 Carrier
	93 Usage
	93 Sounds and the Ring/Silent Switch
	94 Brightness
	95 Wallpaper
	95 General
	99 Mail
	101 Phone
	103 Safari
	104 iPod
	106 Photos
	106 Restoring or Transferring Your  Settings

Chapter 9	108	iTunes Wi-Fi Music Store
	109	Browsing and Searching
	111	Purchasing Songs and Albums
	112	Syncing Purchased Content
	113	Verifying purchases
	113	Changing Your iTunes Store Account Information
Appendix A	114	Tips and Troubleshooting
	114	General Suggestions
	119	Removing the SIM Card
	120	Updating and Restoring [redacted] Software
	120	Using [redacted] Accessibility Features
Appendix B	122	Learning More, Service, and Support
Index	124	



To avoid injury, read all operating instructions in this guide and safety information in the *Important Product Information Guide* at www.apple.com/support/manuals/ before using .

What You Need

To use you need:

- A new wireless service plan with the carrier that provides service in your area
- A Mac or a PC with a USB 2.0 port and one of the following operating systems:
 - Mac OS X version 10.4.10 or later
 - Windows XP Home or Professional with Service Pack 2 or later
 - Windows Vista Home Premium, Business, Enterprise, or Ultimate edition
- Display resolution on your computer set to 1024 x 768 or higher
- iTunes 7.5 or later, available at www.apple.com/itunes
- An iTunes Store account (a major credit card is required to open a new account)
- An Internet connection

Activating

Before you can use any of s features, you must activate by signing up for a service plan with the service carrier in your area and registering with the network. If you already have a wireless account with the carrier, you may be able to upgrade your account to work with or keep using your old phone and add a new line for (Some accounts may not be upgradable.) You may also be able to transfer your current phone number to or get a new one.

For more information about including videos about how to activate and use it, go to:

www.apple.com/

Inserting the [REDACTED] SIM Card

In some regions, you may need to purchase the SIM card separately and insert it into [REDACTED] before activation. Read the documentation that comes with the SIM card for instructions.

If your carrier gave you a PIN number to use with your SIM, you may need to enter the PIN before activating [REDACTED]

Activate [REDACTED]

- 1 Download and install the latest version of iTunes from www.apple.com/itunes.
- 2 Connect [REDACTED] to a USB 2.0 port on your Mac or PC using the dock and cable that came with [REDACTED]

Unless your keyboard has a high-powered USB 2.0 port, you must connect [REDACTED] to a USB 2.0 port on your computer.



- 3 Follow the onscreen instructions in iTunes to activate [REDACTED] and sync [REDACTED] with your contacts, calendars, email accounts, and bookmarks on your computer.


A single checkmark in “Set Up Your [REDACTED]” syncs all these items automatically. Or you can use iTunes to customize the information you sync, and to sync your ringtones, music, photos, podcasts, and videos to [REDACTED]. See the following section.

You can disconnect [REDACTED] from your computer after “Waiting for activation” appears on the [REDACTED] screen. When activation is complete, “[REDACTED] is activated” appears on the [REDACTED] screen. This means that [REDACTED] is fully functional and you can use all of its features.

Important: If you are migrating your current phone number to [REDACTED], activation may take from several hours to a day and migration of your number may take several days, depending on your location and previous carrier.

Syncing [redacted] with Your Computer

When you connect [redacted] to your computer, iTunes syncs [redacted] with the information and media on your computer, according to how you've configured the [redacted] sync settings in iTunes.



You can set iTunes to sync any or all of the following:

- Contacts—names, phone numbers, addresses, email addresses, and so on
- Calendars—appointments and events
- Email account settings
- Webpage bookmarks
- Ringtones
- Music and audiobooks
- Photos
- Podcasts
- Videos

Ringtones, music, audiobooks, podcasts, and video content are synced from your iTunes library. If you don't already have content in iTunes, the iTunes Store (available in some countries) makes it easy to purchase or subscribe to content and download it to iTunes. You can also add music to your iTunes library from your CDs. To learn about iTunes and the iTunes Store, open iTunes and choose Help > iTunes Help.

Contacts, calendars, webpage bookmarks, and photos are synced from applications on your computer, as described below. Contacts and calendars are synced both ways between your computer and [redacted]. New entries or changes you make on [redacted] are synced to your computer, and vice versa. Webpage bookmarks are also synced both ways.

Email account settings are only synced from your computer's email application to [redacted]. This allows you to customize your email accounts on [redacted] without affecting email account settings on your computer.

If you like, you can set [redacted] to sync with only a portion of what's on your computer. For example, you might want to sync only a group of contacts from your address book, or only unwatched video podcasts. You can adjust sync settings whenever [redacted] is connected to your computer.

Important: You can connect and sync with only one [redacted] at a time. Disconnect one before connecting another. You should be logged in to your own user account on the computer before connecting [redacted]. On a PC, if you sync more than one [redacted] to the same user account, use the same sync settings for each.

Setting Up Syncing

You use the [redacted] settings panes in iTunes to specify the iTunes content and other information you want to sync to [redacted]



Set up syncing

- 1 Connect [redacted] to your computer, and open iTunes (if it doesn't open automatically). Unless your keyboard has a high-powered USB 2.0 port, you must connect [redacted] to a USB 2.0 port on your computer.
- 2 Select [redacted] in the iTunes window (below Devices, on the left).
- 3 Configure the sync settings in each of the settings panes.
- 4 Click Apply in the lower-right corner of the screen.

The following sections provide an overview of each of the [redacted] settings panes. For more information, open iTunes and choose Help > iTunes Help.

