



Tactile Function Switches




Encoder


EN1
Optical Encoder 120ppi




LED's D1-D4




LED Power On




VFOA/VFOB/RIT Switch




Bypass Switch




AUX1 / AUX2 / AUX3 OUTPUTS



Power Supply +5 and +3.3v




RS232/TTL





In/Out to Computer




In/Out to KX3



CPU



Mounting Holes



Software Version 1.xx
LED's and all SMD parts are on the back of the PCB
Tactile switches and encoder solder on front of PCB
(C) Ken Kaplan, 2021 All Rights Reserved

Sheet: /
File: KX3SMD1SideSingleBoardKnob.sch

Title: KX3 Remote Tuning Knob / Switches SMT devices

Size: USLetter Date: 2021-08-03
KiCad E.D.A. kicad (5.1.6)-1

Rev: 1.0
Id: 1/1