




SmarterHome Plug With Energy Meter User Manual

Features

- Apps available on Android phone and iPhone
- Remotely control via phone
- Set your schedule
- Energy Saver
- Anti-theft timer
- Group Access
- Sharing feature



IMPORTANT

**PLEASE READ
BEFORE USING
THIS PRODUCT**

.....Reset Button

.....Indicator light

Before you Start

Remove your Smart Socket from the packaging. Insert it into an appropriate electric outlet. Now connect your electric device to the Smart socket using the switch connected to the electric device. Follow any precautions and instructions as per the electric device.


Quick Start

Step One: Download Kogan SmarterHome app from App Store or Google Play. Register account.

2. Launch the app. Click "Register".
3. Select your country code, enter mobile phone number and the tap "Get" to get a message containing a verification code.
4. We'll send you a verification code. Enter it in the "Verification Code" field, set your password and tap "Login".

Step Two: Now screw in the smart Wi-Fi bulb, power on.

Step Three: Add device.




1. Tap “+” or “Add Device” button of the “Devices” window. The Add Device screen appears (as shown in the picture). Select Smart Power.

2. Make sure the bulb quickly flashes and then tap “next step”. If the light is not flashing quickly, turn the bulb off and on for 3 times until it flashes. Tap “next step”.

3. The “Add Successfully” message appears once connected.

AP MODE

If the SmarterHome device cannot connect due to an unstable network connection, you may receive a "Failed to Add" message. You can use "AP Mode" instead.



1. When the Internet status is unstable, the “Failed to Add” screen appears. Click Cancel on the upper left to go back, and click AP Mode on the upper right.

2. Make sure your device is blinking slowly. If not, follow the instructions on the screen “How to make light slowly blink” . Press “Confirm light slowly blink”

3. Select your WiFi (2.4Ghz only) and enter Wi-Fi Password for your device to connect later. Click “Confirm”.

3. Click “Connect Now” to go to system Settings in Wi-Fi. Choose the Network named SmartLife-XXX, then back to the app.
4. The app page goes through the changes during the configuration process and then once connected, the “Add Successfully” message appears.

Alexa and Google Home

For detailed instructions on using your Kogan SmarterHome device with Alexa and Google Home, simply access your full product manual by searching the product name at the following link: <https://www.kogan.com/usermanuals/>

CONTROL PANEL

After selecting a Smart Socket from the 'Devices' screen, the Smart Socket Control Panel screen appears.

CONTROL PANEL: SOCKET ON

Tap the socket's image in the middle to switch the Smart Socket ON or OFF. When the Smart Socket is switched on, the socket's Control Panel options are displayed.

CONTROL PANEL: SOCKET OFF

Tap the socket image in the middle to switch the Smart Socket ON or OFF. When the Smart Socket is switched on, the socket's Control Panel options are displayed.

CONTROL PANEL OPTIONS:


When the Smart Socket is switched on, the switch's Control Panel options are displayed. The following options appear: Switch, Shedule, Timer, Statistics (only available to the model with this function)

Switch: Switches the Smart Socket's power ON and OFF.


Schedule: Adds scheduled timers for turning the Smart Socket on/off.

Timer: Sets a timer countdown for turning off the socket.


Statistics: Calculates power consumption. (Only available to the model with this function)



SOCKET ON



SOCKET OFF



Electrical quality management

PROFILE


"Profile" allows you to manage your personal information.

Tap the "Profile" button from the "Devices" screen to open the Profile options. The options include:


1. Personal Information: Tap the "Profile" to edit nickname, profile picture, and change account password. Tap "Logout" to logout of the app. Upon reentering the Kogan SmarterHome app you will need to login again.
2. Device Sharing: Displays information of shared devices.
3. Message Center: Displays messages.
4. Feedback: Allows you to submit feedback.
5. FAQ: Displays common questions and answers about the device and app.
6. About: Displays the application version, checks for updates, and allows you to rate the app.
7. Settings: Tap to set the sounds and vibration of your mobile device and to logout of the application

PROFILE: DEVICE SHARING

1. Tap "Device Sharing" from the "Profile" screen to open the "Sharings Sent" tab.
2. Tap "Add Sharing" (Picture 1).
3. Enter phone number, Nickname, and relation then tap "Confirm" to confirm and save the information (Picture 2).
4. The list of names added to sharing is displayed.
5. Tap the added Sharing that you sent to edit the name. Tap "Done" to save your changes.
6. To delete, touch a listed profile sent name and slide your finger to the left. The Delete option appears. Tap "Delete" to remove the shared user.
7. Tap the "Sharings Received" tab to view the list of devices that your account has received



Picture 1



Picture 2