




Power Supply 5V to 3.3V



USB to serial connverter



ESP12E Core



By Ashwin CS
ESP8266 Basic board
Use 3.3v UsB to Serial Programmer

SCINTILLA

Sheet: /
File: ESP12E Programmer board.sch

Title: ESP12E

Size: A4
KiCad E.D.A. kicad 5.1.10-88a1d61d5888ubuntu18.04.1

Date: 2021-04-29

Rev: 1.0.1

Id: 1/1