




NRF54L15-QFAA-R




Q3F1






Power managment

nPM1300-QEAAC0




Linear resonant driver

DRV2603




BTB connector

To RGB unit




Battery protection

XB6536A




BTB connector

[To main unit](#)



Battery connector



ERM connector