





Programming & debug



- BUSY/SYNC_1 TP1
- SW_1 TP2
- FLAG_1 TP3
- STEP_CLK_1 TP4
- STBY/RST TP5
- MOTOR_CS TP6
- MOTOR_SCK TP7
- MOTOR_MOSI TP8
- MOTOR_MISO TP9

USB connector with protection



VBUS is not connected: otherwise after enabling USB pull-up inside STM, +3v3 will present at VBUS even after cable disconnect, causing USB_DISCONN event failure.

