

## Troubleshooting Guide

---

Problem: Washing machine does not start

Solution:

- Ensure the power cable is plugged in.
- Check the fuse in the plug.
- Verify the door is properly closed.

Problem: Refrigerator not cooling properly

Solution:

- Check temperature settings.
- Ensure the door is closing tightly.
- Avoid overloading the fridge.