


Layer: User Interface



Left-to-Right:

- Manual Press (MP)
button
- Reset Delay on MP_{switch}
- Timing Delay Knob

Screen to include
Relevant information

4/27/15