






Raspberry Pi Zero2 (Fixed)



Jumper to disconnect 5V from User Port

Actual C64 User Port



Connections through 74HC245:

TxD_Pi -> RxD_64 (A1 -> B1) Data from Pi to 64

TxD_64 -> RxD_Pi (A2 -> B2) Data from 64 to Pi

Pi is 3.3V, C64 is 5V