


main menu



Left button:

Start


Right button:

Increment profile 0-9, and circle

Both buttons:

Open profile setup

Profile setup



Left button:

Edit setting

Right button:

Cycle settings, until last setting is reached, then return to the main menu

Both buttons:


Return to the main menu




Letters shown: EX, represents scrolling text saying Exposure time Settings list is as follows:




1. Exposure time
 1. default: 0.01 seconds
 2. range: 0.01 seconds - 9 hours 50 minutes (increments: .01, .02,1°, .2° ... 1, 2 ... 66, 1h1°, 1h2°, 1h3° ... 9h5°)
2. Delay before first picture
 1. default: 0
 2. range: 0 seconds - 9 hours 50 minutes (increments: 0, 1, 2 ... 66, 1h1°, 1h2°, 1h3° ... 9h5°)
3. Amount of pictures
 1. default: 1
 2. range: ∞, 1 - 999 (∞ acts as -1 in the ui)
4. Repeat delay
 1. default: 1 second
 2. range: 0.01 seconds - 9 hours 50 minutes (increments: 0, .1°, .2° ... 1, 2 ... 66, 1h1°, 1h2°, 1h3° ... 9h5°)
5. Brightness during exposure
 1. default: 10
 2. range: 0 - 100
6. Master brightness
 1. default: 100 (affects all profiles and the main menu)
 2. range: 1 - 100
7. Focus time before taking picture
 1. range: 0.01 seconds - 9 hours 50 minutes (increments: 0, .1°, .2° ... 1, 2 ... 66, 1h1°, 1h2°, 1h3° ... 9h5°)

Edit setting

Integer







Time

