

Information about product item_number: 13
PowerBurner Camping Stove, price \$100,

Brand
PowerBurner

Category
Camping Stoves

Features

- Dual burners for efficient cooking
- High heat output for fast boiling and cooking times
- Adjustable flame control for precise temperature regulation
- Compact and portable design for easy transportation
- Piezo ignition system for quick and reliable ignition
- Wind-resistant design to withstand outdoor conditions
- Removable cooking grates for easy cleaning
- Built-in fuel regulator for consistent performance
- Sturdy construction for durability and stability
- Compatible with various fuel types (propane, butane, etc.)
- Integrated carrying handle for convenient portability
- Made with high-quality materials for long-lasting use

Technical Specs

- **Best Use**: Camping, Outdoor Cooking
- **Material**: Stainless Steel
- **Fuel Type**: Propane, Butane, compatible with various fuel types
- **Color**: Black
- **Burner Type**: Dual Burners
- **Heat Output**: High heat output for fast boiling and cooking times
- **Flame Control**: Adjustable flame control for precise temperature regulation
- **Ignition System**: Piezo ignition system for quick and reliable ignition
- **Wind Resistance**: Wind-resistant design to withstand outdoor conditions
- **Construction**: Sturdy construction for durability and stability
- **Fuel Regulator**: Built-in fuel regulator for consistent performance
- **Cooking Grates**: Removable cooking grates for easy cleaning
- **Portability**: Compact and portable design with integrated carrying handle
- **Compatibility**: Compatible with standard camping fuel canisters
- **Dimensions**: 14in x 14in x 10in
- **Weight**: 5 lbs

User Guide/Manual

1. Safety Instructions

- Read and understand all instructions before using the camping stove.
- Only use the camping stove in well-ventilated outdoor areas.
- Keep the camping stove away from flammable materials, including tents and overhanging branches.
- Never leave the camping stove unattended while it is in use.

- Use caution when handling the camping stove, as it can become hot during operation.
- Keep children and pets away from the camping stove.
- Follow all local fire safety regulations and guidelines.

2. Setup and Assembly

- Select a flat and stable surface for setting up the camping stove.
- Remove the stove from its packaging and unfold the legs.
- Attach any included accessories such as windshields or side tables, if applicable.

3. Fuel Selection and Connection

- Choose the appropriate fuel type for your camping stove (propane, butane, etc.).
- Follow the manufacturer's instructions for connecting the fuel canister to the stove.
- Ensure a secure and tight connection between the fuel canister and the stove.

4. Ignition and Flame Control

- Locate the ignition system (typically a piezo igniter) on the camping stove.
- Turn the control knob to the "Ignite" or "Start" position and press the ignition button to ignite the burners.
- Adjust the flame control knob to increase or decrease the flame intensity.

5. Cooking Tips

- Place cookware on the cooking grates and ensure stability.
- Use suitable cookware that matches the size of the burners.
- Monitor the cooking process closely and adjust the flame as needed.
- Avoid placing flammable materials near the camping stove during cooking.

6. Cleaning and Maintenance

- Allow the camping stove to cool down completely before cleaning.
- Clean the cooking grates and stove surface using mild soap and water.
- Remove any food residue or grease buildup from the burners.
- Store the camping stove in a clean and dry place.

Caution Information

1. ****DO NOT**** use the camping stove indoors or in poorly ventilated areas. It is designed for outdoor use only.
2. ****DO NOT**** leave the camping stove unattended while it is in use.
3. ****DO NOT**** place flammable materials or objects near the camping stove during operation.
4. ****DO NOT**** use the camping stove in windy conditions without proper wind protection or shielding.
5. ****DO NOT**** touch the stove surfaces or components while they are hot. Always use heat-resistant gloves or utensils.
6. ****DO NOT**** use the camping stove with a damaged or leaking fuel canister. Check for any leaks or defects before connecting.
7. ****DO NOT**** modify or alter the camping stove in any way. Use it as intended and follow the manufacturer's instructions.

8. ****DO NOT**** attempt to disassemble or repair the camping stove yourself. Contact authorized service personnel for assistance.
9. ****DO NOT**** use the camping stove if you suspect a malfunction or if it shows signs of damage. Discontinue use and seek professional inspection.
10. ****DO NOT**** expose the camping stove to extreme temperatures or direct sunlight for prolonged periods when not in use.

Certainly! Here's a sample warranty information for the PowerBurner Camping Stove:

Warranty Information

1. Warranty Coverage:

- The PowerBurner Camping Stove is covered by a ****1-year limited warranty**** from the date of purchase.
- The warranty covers manufacturing defects in materials and workmanship under normal use.
- The warranty is valid only for the original purchaser and is non-transferable.

2. Warranty Exclusions:

The warranty does not cover the following:

- Damage caused by misuse, abuse, negligence, accidents, or improper maintenance.
- Normal wear and tear, including scratches, dents, or fading of the finish.
- Damage caused by unauthorized repairs or modifications.
- Damage caused by using the camping stove for purposes other than intended.
- Damage caused by using incompatible or improper fuel.

3. Warranty Claim Procedure:

In the event of a warranty claim, please follow these steps:

- Contact our customer care center within the warranty period to initiate a warranty claim.
- Provide proof of purchase, including the date of purchase and the retailer from whom the product was purchased.
- Describe the issue or defect in detail and provide any supporting documentation or images, if applicable.
- Our customer care team will guide you through the warranty claim process, which may involve inspection, repair, or replacement of the camping stove.

4. Contact Information:

If you have any questions or need assistance with your PowerBurner Camping Stove, please contact our customer care team:

- Customer Care Phone: 1-800-213-2314
- Customer Care Email: support@powerburner.com
- Website: www.powerburner.com/support

Return Policy

- ****If Membership status "None":**** If you are not satisfied with your purchase, you can return it within 30 days for a full refund. The product must be unused and in its original packaging.
- ****If Membership status "Gold":**** Gold members can return their camping stoves within 60 days of purchase for a full refund or exchange. The product must

be unused and in its original packaging.

- **If Membership status "Platinum":** Platinum members can return their camping stoves within 90 days of purchase for a full refund or exchange. The product must be unused and in its original packaging. Additionally, Platinum members receive a 10% discount on all camping stove purchases but from the same product brand.

Reviews

1) **Rating:** 5

Review: I absolutely love the PowerBurner Camping Stove! It's compact, lightweight, and incredibly efficient. It heats up quickly and provides a consistent flame for cooking. The adjustable heat control is a great feature, allowing me to simmer or boil with ease. The sturdy construction and durable materials give me confidence in its longevity. It's definitely a reliable companion for all my camping adventures!

2) **Rating:** 4

Review: The PowerBurner Camping Stove is a solid choice for outdoor cooking. It's easy to assemble and disassemble, making it convenient to transport. The flame output is consistent, and the heat is well-distributed. I appreciate the built-in wind protection, which helps maintain a steady flame even in windy conditions. The stove is sturdy and stable, providing a reliable cooking surface. The only downside is that it's a bit bulky compared to other camping stoves I've used, but overall, it's a reliable and functional option.

3) **Rating:** 3

Review: The PowerBurner Camping Stove gets the job done, but it has some room for improvement. The flame control is a bit tricky, and it can be challenging to achieve a low simmer. The ignition system works well most of the time, but occasionally it takes a few tries to get it going. On the positive side, it's fairly lightweight and easy to carry. The construction is decent, but I would prefer a more durable feel. It's an average camping stove that serves its purpose adequately.

4) **Rating:** 5

Review: I'm impressed with the performance of the PowerBurner Camping Stove. It's compact, yet powerful enough to cook meals quickly. The flame is adjustable and provides excellent heat control. The integrated piezo ignition is reliable and saves me the hassle of carrying a separate lighter. The stove is easy to clean, and the included carrying case is a nice bonus. I've used it on multiple camping trips, and it has never let me down. Highly recommended for outdoor cooking enthusiasts!

5) **Rating:** 4

Review: The PowerBurner Camping Stove is a solid choice for camp cooking. It's easy to set up and operate, and the flame is consistent and reliable. The stove is stable on various surfaces, thanks to its sturdy design. The included windscreen is effective in protecting the flame from gusts of wind. The only minor drawback is that the control valve is a bit sensitive, requiring careful adjustment to achieve the desired heat level. Overall, it's a reliable camping stove that delivers good performance.

FAQ

59) Can the PowerBurner Camping Stove be used with both propane and butane?

Yes, the PowerBurner Camping Stove is compatible with both propane and butane fuel canisters, allowing you to choose the most convenient option for your needs.

60) How easy is it to clean the PowerBurner Camping Stove after use?

The PowerBurner Camping Stove is designed for easy cleaning, with removable pot supports and a stainless steel construction that can be wiped down with a damp cloth after it has cooled down.

61) How long do fuel canisters last with the PowerBurner Camping Stove?

Fuel consumption for the PowerBurner Camping Stove depends on factors like burner intensity and altitude. On average, a 16 oz propane canister can last between 1 to 2 hours of continuous use on high heat.

62) Can I use the PowerBurner Camping Stove indoors?

The PowerBurner Camping Stove is designed for outdoor use only. Using it indoors can lead to dangerous carbon monoxide buildup, which poses a serious risk to your health and safety.