

## Adjusting the tilt

The fan has a tilt angle of  $-15^{\circ}$  to  $+35^{\circ}$ . You can adjust this in steps of  $5^{\circ}$ .



1. Hold the fan by the handle at the top.
2. Tilt the fan until it is at the desired angle of tilt.

Note: A clearly audible click indicates that the tilt angle has changed by one step.

Figure 1: Adjusting the tilt