

Sheet: power_supply

File: power_supply.sch

Sheet: can







File: can.sch

Sheet: rs_485

File: rs_485.sch

Sheet: ethernet

File: ethernet.sch






Sheet: /
File: IoTGW.sch


Title: IoTGW

Size: A4 Date: 2021-01-26
KiCad E.D.A. kicad 5.1.9-73d0e3b20d88ubuntu20.04.1


Rev: 1.0
Id: 1/5



Sheet: /power_supply/	
File: power_supply.sch	
Title: IoTGW	
Size: A4	Date: 2021-01-26
KiCad E.D.A. kicad 5.1.9-73d0e3b20d88ubuntu20.04.1	Rev: 1.0
Id: 2/5	



Sheet: /can/ File: can.sch	
Title: IoTGW	
Size: A4	Date: 2021-01-26
KiCad E.D.A. kicad 5.1.9-73d0e3b20d88ubuntu20.04.1	Rev: 1.0 Id: 3/5



Sheet: /rs_485/
File: rs_485.sch

Title: IoTGW

Size: A4 Date: 2021-01-26
KiCad E.D.A. kicad 5.1.9-73d0e3b20d88ubuntu20.04.1

Rev: 1.0
Id: 4/5

