

Sheet: power_supply

File: power_supply.sch

Sheet: can







File: can.sch

Sheet: rs_485

File: rs_485.sch

Sheet: ethernet

File: ethernet.sch



FID1
Fiducial

FID2
Fiducial




Sheet: /
File: IoTGW.sch

Title:

Size: A4
KiCad E.D.A. kicad 5.1.8-db983349188ubuntu20.04.1

Date:

Rev:
Id: 1/5



Sheet: /power_supply/
File: power_supply.sch

Title:


Size: A4

Date:


KiCad E.D.A. kicad 5.1.8-d8983349188ubuntu20.04.1

Rev:

Id: 2/5



Sheet: /can/ File: can.sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad 5.1.8-d	db983349188ubuntu20.04.1	Id: 3/5



Sheet: /rs_485/
File: rs_485.sch

Title:

Size: A4
KiCad E.D.A. kicad 5.1.8--db983349188ubuntu20.04.1

Date:
Id: 4/5

Rev:

