

Lur Lab Audio Board Operation

On/Off	Start and Stop Audio
Left	Move Left to Frequency Menu
Right	Move Right to Volume Menu
Up	Scroll Up
Down	Scroll Down

In **Frequency Menu** scroll up or down through the following items:

2 kHz	Play 2 kHz Tone
4 kHz	Play 4 kHz Tone
8 kHz	Play 8 kHz Tone
12 kHz	Play 12 kHz Tone
16 kHz	Play 16 kHz Tone
24 kHz	Play 24 kHz Tone
32 kHz	Play 32 kHz Tone
Random	Play All Tones in Random Order
Noise	Play Noise

In **Volume Menu** scroll up or down through the Volume Settings 0-43

