

NOTICE

There are two firmware for SplashDrone 4 remote control. Please use the right firmware to update your remote control. Sorry for the inconvenience.

Here is how to choose the right firmware for your remote control:

1. Look for the sticker on the phone stand.
2. Check the number on it.
3. Use the corresponding firmware to update your remote control.
(with or without X)



With X



Without X

If you find your remote control's screen is not working properly, you might update to the wrong firmware. Don't worry. Try to update it again using the right one.