

# Welcome to Teensy 3.2

## 32 Bit Arduino-Compatible Microcontroller

To begin using Teensy, please visit the website & click Getting Started.

[www.pjrc.com/teensy](http://www.pjrc.com/teensy)

### Digital Pins

digitalRead  
digitalWrite  
pinMode

### Analog Pins

analogRead  
analogReference  
analogReadRes

### PWM Pins

analogWrite  
analogWriteRes

### Touch Sense Pins

touchRead

### Serial Ports


Serial1  
Serial2  
Serial3

### I<sup>2</sup>C Port

Wire Library


### SPI Port

SPI Library



# Teensy 3.2 Back Side

Additional pins and features available on the back side



For solutions to the most common issues  
and technical support, please visit:

[www.pjrc.com/help](http://www.pjrc.com/help)

Teensy 3.2 System Requirements:

PC computer with Windows 7, 8, 10 or later

or Ubuntu Linux 12.04 or later

or Macintosh OS-X 10.7 or later

USB Micro-B Cable

