




sirosupdater

General installation procedure

Step 1: Install USB driver for Siros

This has to be done only once per PC. Further updates do not require step 1.

Step 2: Update Siros with Siros Updater

Name	Änderungsdatum	Typ	Größe
 Step 1 - Siros Updater USB Driver	03.07.2015 14:46	Dateiordner	
 Step 2 - Siros Updater Tool	03.07.2015 14:46	Dateiordner	
 Instructions - Follow those steps.pdf	03.07.2015 14:41	Adobe Acrobat D...	542 KB





How to install the USB driver

System requirements: Windows 7 and higher







1. Open folder *Step 1 - Siros Updater USB Driver*

2. Now open folder x64

If your computer is a 32bit system you will be prompted to install the 32bit driver.
 Please open then folder *Step 1 - Siros Updater USB Driver/x86*

Name	Änderungsdatum	Typ	Größe
 x64	03.07.2015 14:46	Dateiordner	
 x86	03.07.2015 14:46	Dateiordner	
 Microchip_EULA.txt	27.10.2014 15:37	TXT-Datei	13 KB
 Release Notes.txt	27.10.2014 15:37	TXT-Datei	4 KB


3. Double click on the file *McphCdcDriverInstallationTool.exe*.

Name	Änderungsdatum	Typ	Größe
 157x318.bmp	27.10.2014 15:37	Bitmapbild	147 KB
 dpinst.xml	27.10.2014 15:37	XML-Dokument	16 KB
 mchp.ico	27.10.2014 15:37	Symbol	44 KB
 mchpcdc.cat	27.10.2014 15:37	Sicherheitskatalog	9 KB
 mchpcdc.inf	27.10.2014 15:37	Setup-Informatio...	5 KB
 McphCdcDriverInstallationTool.exe	27.10.2014 15:37	Anwendung	1 022 KB

4. The following picture will be displayed.



5. Click on the button *Next* and select *I accept*




6. Click on the button *Next*. The driver will be installed. The following end message window will be displayed.



7. Click *Finish*. The Siros USB driver is now installed.

How to do the update Siros with Siros Updater

1. Select the folder *Step 2 - Siros Updater Tool*
2. Double click on the file *SirosUpdater.exe*. The following window will be displayed



3. Please follow the instructions on the screen.