



## Create project for existing code:


1)




2)



### 3) Select project and right click – Properties



### 4) Uncheck “Use default build” command and write down the text as shown in the next picture.




## Build - Eclipse:


Press build to build your project.

## Configuration of the Debugging - Eclipse:

### 1) Main



### 2) Debugger



### 3- Startup

Debugger Startup Configuration

Initialization Commands

☒ Initial Reset. Type:

☒ Enable Arm semihosting

Load Symbols and Executable

☒ Load symbols

☒ Use project binary:

☐ Use file:

Symbols offset (hex):

☒ Load executable

☒ Use project binary:

☐ Use file:

Executable offset (hex):

Runtime Options

☐ Debug in RAM

Run/Restart Commands

☒ Pre-run/Restart reset Type:  (always executed at Restart)

☐ Set program counter at (hex):

☒ Set breakpoint at:

☒ Continue