

- RED Wire to RED Channel (TOP)
- Blue/Black/Brown Wire to Blue Channel (TOP)
- Data (Green) Wire to end of the resistor.

