


How to Enable the Calendar




1. Click the POWER icon to turn off the generator (switch left, color red).
2. Click the SETTINGS icon.
3. Click the ENABLE CALENDAR icon.
4. Select the ON option using the arrows.
5. Click the SAVE icon to confirm your selection.
6. Click the BACK icon to go to the homepage.
7. Check if the option ENABLE CALENDAR is set to ON to confirm it was successfully

updated.

8. If you want to start the generator, click the POWER icon to turn it on (switch right, color green).

The generator now produces ozone only during the times set in the calendar.

How to Disable the Calendar



1. Click the POWER icon to turn off the generator (switch left, color red).
2. Click the SETTINGS icon.
3. Click the ENABLE CALENDAR icon.
4. Select the OFF option using the arrows.
5. Click the SAVE icon to confirm your selection.
6. Click the BACK icon to go to the homepage.
7. Check if the option ENABLE CALENDAR is set to OFF to confirm it was successfully updated.

The generator now produces ozone continuously, ignoring the times set in the calendar.