

# WELCOME TO MEMBRANE

## What's Membrane?

Membrane is a Sega Genesis musical instrument for one or two players. Its sound and playing style are inspired by the ocarina.

## How to Play a Note

The controls for both players are identical. Use the Fingering buttons (A, B, C) to set the pitch, then press the Action button (D-pad Right) to sound the note.

If Sustain mode is OFF, releasing the Action button will immediately silence the note. If Sustain mode is set to STRUM, the note will continue to play after the Action button is released until the Silence button (D-pad Left) is pressed.

Changing the fingering while the Action button is held down will result in the current note changing its pitch. STRUM allows you to circumvent this by tapping the Action button instead of keeping it held down.

## Fingerings



Do



Ra/Re



Me/Mi



Fa/Fi



Se/Sol/Si



Le/La/Li



Te/Ti



Do

# CONTROLS

## Normal Controls



## Controls with Start Button Held Down

